

How to assign an IP address and access your device

How to assign an IP address and access your device

Table of Contents

Get started	3
Browser support	3
About default IP addresses	4
AXIS IP Utility	5
Access your device on the network	5
Change the IP address of a device	5
AXIS Device Manager	6
Access your device on the network	6
Change the IP addresses of multiple devices	6
Change the IP address of a device	6
Other methods	8
Improve your device's security	9
About secure passwords	9
Set a secure password for the root account	9
About user accounts	9
Further information	10

How to assign an IP address and access your device

Get started

Get started

To find Axis devices on the network and assign them IP addresses in Windows®, use AXIS IP Utility or AXIS Device Manager. Both applications are free and can be downloaded from www.axis.com/support

With AXIS IP Utility you can:

- search the network for devices
- change static IP addresses

With AXIS Device Manager you can:

- search the network for devices
- assign IP addresses
- set passwords
- see connection status
- perform operations on multiple devices at once
- manage firmware upgrades
- configure device parameters

Do you want information about other methods? See *Other methods on page 8*.

Browser support

You can use the device with these browsers:

Windows®

- Chrome™ (recommended)
- Firefox®
- Edge®
- Opera®

OS X®

- Chrome™ (recommended)
- Safari®

Other operating systems

- Chrome™
- Firefox®

To find out more about how to use the device, see the User Manual available at www.axis.com

If you want more information about recommended browsers, go to www.axis.com/browser-support

How to assign an IP address and access your device

Get started

About default IP addresses

Axis devices are designed to be used on an Ethernet network. To access the device's webpage you need an IP address. Most networks have a DHCP server that automatically assigns IP addresses to connected devices.

If your network does not have a DHCP server the default IP address is 192 . 168 . 0 . 90.

How to assign an IP address and access your device

AXIS IP Utility

AXIS IP Utility

Note

The computer running AXIS IP Utility must be on the same network segment (physical subnet) as the Axis device.

Access your device on the network

1. Connect power and network to the Axis device.
2. Start AXIS IP Utility. All available devices on the network show up in the list automatically.
3. To access the device from a browser, double-click the name in the list.

Change the IP address of a device

1. Start AXIS IP Utility. All available devices on the network show up in the list automatically.
2. Right-click the device in the list and select **Assign new IP address to selected device**.
3. Enter an available IP address and click **Assign**.
4. To access the device from a browser, double-click the name in the list.

How to assign an IP address and access your device

AXIS Device Manager

AXIS Device Manager


Access your device on the network

1. Connect power and network to the Axis device.
2. Start AXIS Device Manager.
3. To connect to a server, go to **Main menu > Servers > New connection**:
 - If the server is on the network, select **Remote server** and select a server from the drop-down list or enter the IP address or DNS address in the **Remote server** field.
 - If the server is running locally on the computer, select **This computer**.
4. To log in as the current Windows user, click **Log in**.


If you clear **Log on as current user** you need to enter a username and password in the next step.
5. Add devices:
 - AXIS Device Manager automatically searches for Axis devices on the network and adds them to the list of devices.
 - To manually add devices, go to **Device management > Add devices**. Select which devices you want to add from the list, click **Next**, and then click **Finish**.
 - To add devices from an IP range, go to **Device management > Add devices from IP range**.
 - To add a device from a specific IP address, go to **Device management > Add device from address**.
6. To access the device from a browser, click the address link in the list.

Change the IP addresses of multiple devices

To speed up the process of assigning IP addresses, AXIS Device Manager suggests IP addresses from a specified range.

1. In AXIS Device Manager, go to **Device management**.
2. Select the devices you want to configure and then click **Assign IP address to selected devices** .
3. In the **Device maintenance** dialog, click **Yes**.
4. Select **Assign the following IP address range**.
5. To change the suggested IP address range, enter the IP address range in the **IP range** text field.
6. Click **Next**.
7. To change any of the IP addresses, select a device and click **Edit IP**.
8. Click **Finish**.

Change the IP address of a device

1. Select the device you want to configure and then click **Assign IP address to selected devices** .
2. Select **Assign the following IP address**.
3. Enter the IP address, subnet mask, and default router.

How to assign an IP address and access your device

AXIS Device Manager

4. Click OK.

How to assign an IP address and access your device

Other methods

Other methods

The lists below show other methods available for assigning or discovering IP addresses.

Windows®

- UPNP™

UPnP automatically detects Axis devices and adds them to **Network** or **My Network Places**.

Mac OS X® 10.4 or later

- Bonjour (applicable to browsers with support for Bonjour)

Navigate to the Bonjour bookmark in your browser, for example Safari, and click the link to access the webpage.

All operating systems

- DHCP server

To view the admin pages for the network DHCP server, see the server's user documentation.

- Hosted video services

To connect to a hosted video service, see the service provider's installation guide. For information and help in finding a local service provider, go to www.axis.com/hosting

How to assign an IP address and access your device

Improve your device's security

Improve your device's security

About secure passwords

Important

Axis devices send the initially set password in clear text over the network. To protect your device after the first login, set up a secure and encrypted HTTPS connection and then change the password.

The device password is the primary protection for the data and services. Axis devices do not impose a password policy as they may be used in various types of installations. To protect your data we recommend that you:

- Change the default password that comes with the devices.
- Use a password with at least 8 characters, preferably created by a password generator.
- Don't expose the password.
- Change password at a recurring interval, at least once a year.

Set a secure password for the root account

Important

The default administrator user name `root` cannot be deleted. If the password for root is lost, the device must be reset to the factory default settings.

1. Make sure to follow the instructions about secure passwords. See *About secure passwords on page 9*.
2. Type a password and then retype it to confirm the spelling.
3. Click **Create login**. The password has now been configured.

About user accounts

The default root account has full privileges and should be reserved for administrative tasks. Always create a user account with limited privileges for daily use. This reduces the exposure of the administrative account.

How to assign an IP address and access your device

Further information

Further information

- The user manual is available at axis.com
- To check if there is updated firmware available for your device, see axis.com/support
- For useful online trainings and webinars, see axis.com/academy

